

Таблица 3. Модели внутрисхемных симуляторов ICS08

Модель внутрисхемного симулятора	Модели МК, подлежащие отладке
M68ICS08JLJK	MC68HC908JL3, MC68HC908JK3, MC68HC908JK1
M68ICS08GP	MC68HC908GP32
M68ICS08GR	MC68HC908GR4, MC68HC908GR8
M68ICS08MR	MC68HC908MR8, MC68HC908MR16, MC68HC908MR32
M68ICS08KX	MC68HC908KX2, MC68HC908KX8
M68ICS08JB	MC68HC908JB1, MC68HC908JB8
M68ICS08RK	MC68HC908RF2, MC68HC908RK2
M68ICS08SR	MC68HC908SR12
M68ICS08AB	MC68HC908AB32
M68ICS08AS/AZ	MC68HC908AZ60, MC68HC908AZ60A, MC68HC908AS60, MC68HC908AS60A